

PARTS LIST

BC360HT

CONTENTS


1. MAIN BODY	1 ~ 2
2. GEARCASE.....	3 ~ 4
3. ENGINE	5 ~ 8
4. RECOIL STARTER	9 ~ 10
5. CARBURETOR, FUEL TANK	11 ~ 14
6. ACCESSORIES	15 ~ 16

2019. 05.




P/N 524835

1. BC360HT
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	366142	BC360HT	1	
1-2	560481	Clutch Case Ass'y	1	Incl.3-10
1-3	560482	Clutch Case	1	
1-4	140474	Bearing	1	#6202ZZ
1-5	012380	Snap Ring	1	#35
1-6	560483	Clutch Drum	1	
1-7	012384	Snap Ring	1	#15
1-8	560484	Buffer	1	
1-9	560485	Driveshaft Tube Adapter	1	
1-10	065601	Snap Ring	1	H45
1-11	560486	Screw	1	M5x10
1-12	560487	Cap Screw	1	M6x30
1-13	560515	Driveshaft Ass'y	1	
1-14	560488	Driveshaft Tube	1	
1-15	560490	Hanging Bracket Ass'y	1	Incl.16
1-16	560496	Screw	1	M5x25
1-17	560497	Bracket Ass'y	1	Incl.18
1-18	560487	Cap Screw	6	M6x30
1-19	560517	Label	1	MARUYAMA
1-20	560518	Label	1	
1-21	560525	Handle Ass'y-Left	1	Incl.22-24
1-22	560526	Handle	1	
1-23	560522	Label	1	
1-24	560527	Handle Grip	1	
1-25	560520	Handle Ass'y-Right	1	Incl.26-28
1-26	560521	Handle	1	
1-27	560522	Label	1	
1-28	560523	Throttle Trigger	1	
1-29	560528	Safety Cover Ass'y	1	Incl.30
1-30	560487	Cap Screw	2	M6x30
1-31	560583	Hanging Strap Ass'y	1	

2. BC360HT GEARCASE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	560502	Gearcase Ass'y	1	Incl.2-18
2-2	560503	Gearcase	1	
2-3	560504	Bolt	1	M6x8
2-4	560487	Cap Screw	1	M6x30
2-5	019585	Bearing	1	#6001
2-6	560514	Gear Set	1	
2-7	560506	Blade Shaft	1	
2-8	222442	Bearing	1	#6202 2RS
2-9	012380	Snap Ring	1	#35
2-10	019585	Bearing	1	#6001
2-11	058995	Bearing	1	#6001Z
2-12	055186	Snap Ring	1	#12
2-13	055185	Snap Ring	1	H28
2-14	560508	Bracket A Ass'y	1	
2-15	560511	Bracket B	1	
2-16	560512	Stabilizer	1	
2-17	232920	Nut	1	M10x1.25
2-18	560486	Screw	1	M5x10

3. BC360HT ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	875335	Engine	1	FE360TH/05
3-2	279490	Cylinder	1	
3-3	279574	Gasket	1	
3-4	261250	Cap Screw	4	M5x20
3-5	279669	Insulator	1	
3-6	279671	Gasket	1	
3-7	265924	Cap Screw	2	M5x25
3-8	279714	Muffler Comp	1	
3-9	279886	Gasket	1	
3-10	261607	Cap Screw	1	M5x16
3-11	266713	Cap Screw	2	M5x60
3-12	279767	Under Cover	1	
3-13	261607	Cap Screw	1	M5x16
3-14	279770	Top Cover	1	
3-15	285843	Knob	1	
3-16	279498	Crankcase	1	
3-17	261384	Bearing	2	#6201C3
3-18	261385	Oil Seal	1	ISCD12327
3-19	261386	Oil Seal	1	ISCD12227
3-20	016732	Snap Ring	1	#32
3-21	261612	Cap Screw	4	M5x30
3-22	279357	Piston	1	
3-23	246102	Piston Ring	2	
3-24	265068	Piston Pin	1	
3-25	265225	Bearing, Needle	1	
3-26	261393	Clip, Piston Pin	2	
3-27	279329	Crankshaft/Conn. Rod Ass'y	1	
3-28	286905	Clutch Ass'y	1	Incl. 29, 30
3-29	286906	Clutch Shoe	2	(2) Required
3-30	286907	Spring, Clutch	1	
3-31	246377	Clutch Bolt	2	
3-32	262683	Washer	2	8x22x1.2
3-33	262682	Wave Washer	2	
3-34	279702	Fan Cover	1	
3-35	261250	Cap Screw	4	M5x20
3-36	563598	Magneto Ass'y	1	Incl. 37-41
3-37	279362	Rotor/Fan	1	
3-38	246195	Ignition Coil Ass'y	1	Incl. 39-41
3-39	283178	Plug Boot	1	
3-40	272805	Connector	1	
3-41	283272	Insulator	1	
3-42	261076	Woodruff Key	1	3x10
3-43	261417	Nut, Rotor	1	M8
3-44	280381	Spacer	2	
3-45	261256	Cap Screw	2	M4x25

3. BC360HT ENGINE




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	285982	Spark Plug	1	NGK BPM8Y
3-47	286988	Grommet	1	
3-48	269722	Lead	1	
3-49	284541	Wire,Lead	1	
3-50	264588	Clamp	1	
3-51	563590	Label	1	BC360HT

4. BC360HT
RECOIL STARTER




Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	563607	Recoil Starter Ass'y	1	Incl.2-14
4-2	246299	Recoil Ass'y	1	Incl.3-9
4-3	279893	Reel	1	
4-4	279894	Spiral Spring	1	
4-5	279895	Screw	1	
4-6	246300	Rope Ass'y	1	Incl.7-9
4-7	246435	Starter Rope	1	
4-8	287651	Starter Grip	1	
4-9	283511	Rope Stopper	1	
4-10	261421	Starter Pawl Ass'y	1	Incl.11-14
4-11	261726	Pawl Case	1	
4-12	261727	Pawl	1	
4-13	261728	Return Spring	1	
4-14	020299	E-Ring	1	#4
4-15	285736	Nut	1	M8
4-16	281211	Cap Screw	4	M4x20
4-17	563589	Label	1	

5. BC360HT CARBURETOR, FUEL TANK





Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	279777	Carburetor Ass'y	1	Incl.2-18
5-2	246365	Pump Body	1	
5-3	263726	Cover Plate	1	
5-4	283905	Diaphragm, Meterring	1	
5-5	263727	Gasket	1	
5-6	262994	Diaphragm,Fuel Pump	1	
5-7	282576	Gasket	1	
5-8	281486	Main Jet	1	
5-9	261871	O-Ring	1	
5-10	261875	Screw	2	
5-11	264677	Bracket	1	
5-12	261876	E-Ring	1	
5-13	264678	Washer	1	
5-14	261658	Swivel	1	
5-15	261657	Packing	1	
5-16	263737	Screw	4	
5-17	261878	Nut	1	
5-18	263994	Adapter	1	
5-19	282299	Pump	1	
5-20	279839	Pipe	1	
5-21	262587	Gasket	1	Incl.23-27
5-22	279778	Case Ass'y	1	
5-23	279779	Case Body	1	
5-24	279840	Valve	1	
5-25	279841	Lever	1	
5-26	269032	Screw	1	M5x55
5-27	279848	Sleeve	2	
5-28	262720	Cap Screw	2	
5-29	279783	Plate	1	
5-30	279784	Element	1	
5-31	279786	Cleaner Cover	1	Incl.34-44
5-32	286349	Knob	1	
5-33	563586	Fuel Tank Ass'y	1	
5-34	279790	Fuel Tank	1	
5-35	275306	Fuel Tank Cap Ass'y	1	
5-36	274875	Gasket	1	Incl.38-44 Incl.39-42
5-37	563588	Fuel Pipe Pick-up Ass'y	1	
5-38	246118	Fuel Pipe Ass'y	1	
5-39	268065	Grommet	1	
5-40	262649	Fuel Pipe	1	
5-41	261590	Breather	1	
5-42	261117	Clip	1	
5-43	264653	Filter Ass'y	1	
5-44	563014	Clip	1	
5-45	563014	Clip	1	

5. BC360HT CARBURETOR, FUEL TANK



6. BC360HT
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
6-1	560534	Tool Set	1	Incl.2-10
6-2	560535	Tool Bag	1	
6-3	560536	Box Spanner	1	17X19X(+)
6-4	560537	Double-ended Wrench	1	8x10
6-5	560538	Wrench	1	3mm
6-6	560539	Wrench	1	4mm
6-7	560540	Wrench	1	5mm
6-8	560541	Bolt Set	1	Incl.9
6-9	560542	Cap Screw	4	M6x20
6-10	560543	Band	2	8x133L
6-11	560631	Instruction Manual	1	GB/ES/PT